



## Product Description

KT-SUPER 1 is a new product with the patent of code setting which is invented by our engineers. You can input the numeric keys (0-9) for the code required directly, visual and convenient, quick and efficient. It has clock accurate, timer on and off, room temperature display, conversions between Celsius and Fahrenheit degree, Sleep function, code memory and also has unique function of "intelligent cooling" "intelligent heating". So it is your best choice.

Please read this manual carefully before using, which will be a great help for you to use the remote control.

The remote control can be used after setting. Pull side cover of remote control down, put 2 AAA (VM-4, R03) batteries as per polar indicated on battery cabin.

## Patent code set up

1. Find out the codes from code table, there are many groups codes of each brand. Please try the first group, if it does not operate your equipment, try the second, and do it like this until the codes can operate your equipment. Ex: ALPIN, you can choose 0252, if it does not work, please try the 0253 etc.
2. Press the "SELECT" key, the code on LCD will flash. Enter the 4 digit code in turn. Ex: "0252", press the "0" key, "0" stop flashing, the last three numbers flashing, then press the "2" key, the last two numbers flashing, and press the "5" key, the last number flashing, finally press the last number "2", all of the 4 digit code "0252" stop flashing, code entry is now complete. The remote control confirms the code automatically, and you can use the numeric key normally. You can operate your air conditioner now.
3. After the air conditioner on, try other function keys, if they do not work well, please choose the next group of code until all the functions can work. The remote control is 2000 codes in one, so it is invalid when the code greater than 1999.

## Auto-search code setting

If you do not know the brand of your air conditioner, or if your brand is not listed in the code table, please operate as per following steps:

1. Put the remote control aim at your air conditioner, press the "SELECT" key for 5 seconds and then release, remote control is entering the auto-search status, emit the signal continuously, the code flashes and increases. While the air conditioner receives the signal, and send one buzzer, press any key to confirm.
2. Try other function keys, if they do not work, repeat above steps until it is correct.

## Using of "intelligent Cooling" "intelligent heating"

In the summer, press the "intelligent Cooling" only, the air conditioner will be cooled immediately. In the winter, press the "intelligent heating" key only, the air conditioner will be heated immediately. In both status, the air conditioner will let the heating and cooling in a comfortable temperature automatically, and the fan and swing are all automatic. At the same time, it also can adjust the temperature by "Temp.+" "Temp.-" keys as your requires. These two intelligent keys are very good for the children and the old.

## Clock set up

1. Press the "time" key, clock signal flashes.
2. Press "Time +/ Time -" key, adjust to the current time.
3. Press the "time" key again, clock signal stop flashing, the time setting finishes. (If you do not press the "time" key, it also finishes automatically after 15 seconds)

## Timer on

1. Press the "TMR ON" key, the time on LCD flashes
2. Press "TIME +/-" key, adjust the time when you want to make the air conditioner turn on automatically
3. Time on LCD will stop flash after 15 seconds. Setting is complete

## Timer off

1. Press the "TMR OFF" key, the time on LCD flashes
2. Press "TIME +/-" key, adjust the time when you want to make the air conditioner turn off automatically
3. Time on LCD will stop flash after 15 seconds. Setting is complete

## NOTE

1. If press the "TIMER ON" or "TIMER OFF" key twice, timer is cancel.
2. After timer setting is finished, you should make the remote control's emit directs to your air conditioner's receiving location in available distance. If not, it can not work.
3. If you want to watch the time of timer, you should press the "TIMER ON" or "TIMER OFF" key, the LCD will display the time of timer and after 5 seconds it will display current time.

## Room temperature display

Press "Room T" key, it shows current room temperature and as a thermometer

## Conversions between Celsius and Fahrenheit degree

Press the "C/F" key can convert the display between Fahrenheit and Celsius degree.

## Attention

1. If it is not used for a long time, remove the battery to avoid leakage liquid of the battery to damage the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together) After the batteries are replaced every time, it is not necessary to set model code again.
2. As usual the LCD only display the time when pressing model codes "Enter" key, you can find the code and it is showed on LCD. After 5 seconds it returns time.
3. Check carefully that there is no remora between remote controller and Air conditioner when the time on/off doesn't work. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller.
4. The manufacturer keeps the right to change the parameter and function of product.

## Technical Parameters

Controllable distance : Large than 8 meters  
 Power supply voltage: DC 3 V  
 Battery model: Battery AAA(UM-4, R03) × 2  
 Dimension: L165mm × W55mm × D25mm  
 Weight: Approx100g(excl.the batteries)





| Brand      | Model Code                         |
|------------|------------------------------------|
| ALPIN      | 0252, 0253, 0764, 1277, 1789       |
| AUCMA      | 0288-0296, 0462, 1313, 1998        |
| AUX        | 0297-0300, 0451, 0812, 1987        |
| BANSHEN    | 0264, 1288, 1800                   |
| BOERKA     | 0383, 0434, 0436, 0437, 1407, 1972 |
| CARRIER    | 0203-0209, 0456-0458, 0482-0486    |
| CHANGHONG  | 0301-0308, 0813, 1843              |
| CHIGAO     | 0379-0382, 1403, 1916              |
| CHOFU      | 0184-0187, 1209, 1723              |
| CHUNLAN    | 0345-0350, 0450, 0453, 1373        |
| CORONA     | 0155-0163, 0459, 1180, 1995        |
| CONROWA    | 0377, 1401, 1913                   |
| CONSUL     | 0463, 0975                         |
| DAEWOO     | 0203-0209, 0406, 0715, 1942        |
| DAIKIN     | 0171-0183, 0685, 1707              |
| DOCTOR     | 0221, 0449, 1245, 1985             |
| DONGBAO    | 0355-0361, 1385, 1891              |
| DONGXINBAO | 0413, 0925, 1654                   |
| Electrolux | 0216-0220, 1245, 1752              |
| FRESTECH   | 0277, 0789                         |
| FUJITSU    | 0127-0137, 0464, 1152              |
| FUNAI      | 0430, 0481, 1505, 1966             |
| GALANZ     | 0371, 0372, 0883, 1908             |
| General    | 0128-0136, 0639, 0976, 1161        |
| GLEE       | 0398, 0399, 0910, 1935             |
| GOLDSTAR   | 0201, 0466-0469, 0979, 1737        |
| GREE       | 0309-0316, 0482, 0512, 0513        |
| HAIER      | 0266-0272, 0453-0455, 0778         |
| HISENSE    | 0332-0335, 0847, 1359, 1868        |
| HITACHI    | 0118-0126, 0630, 1145              |
| HUABAO     | 0336-0344, 1360, 1878              |
| HUAKE      | 0408, 0920, 1944                   |

| Brand              | Model Code                   |
|--------------------|------------------------------|
| HUAMEI             | 0402, 0460-0465, 1426, 1999  |
| HUALING            | 0317-0325, 0452, 0964        |
| HUIFENG            | 0370, 0882                   |
| HUIKANG            | 0368, 0441-0443, 1392, 1979  |
| HYUNDAI            | 0202, 0433, 0480, 1226, 1969 |
| JDC                | 0373, 0440, 0952, 1909       |
| JINDA              | 0414, 0926, 1950             |
| JINSONG            | 0389-0391, 0446-0448, 1984   |
| JOHSON             | 0245, 0492, 1269, 1516       |
| KANGLI             | 0374, 0375, 1399, 1910       |
| KELON              | 0282-0287, 0473, 0485-0488   |
| KLIMATAIR          | 0225, 0226, 0452, 0737, 1761 |
| KOLIN              | 0416-0418, 1441, 1952        |
| KONKA              | 0397, 0457-0459, 1933        |
| LG                 | 0197-0200, 0514, 1026, 1733  |
| LIANGYU            | 0233, 0451, 0745, 1257       |
| LITTLE DUCK        | 0015-0020, 0530, 1043        |
| LOREN-SEBO         | 0255, 0471, 0472, 0767       |
| MACQUAI            | 0234-0237, 0465, 0746, 1773  |
| MICOM              | 0415, 0927, 1951             |
| MIDEA              | 0260-0265, 1289, 1976        |
| MITSUBISHI         | 0001-0045, 0476-0479, 1502   |
| NORITZ             | 0431, 1455                   |
| PANASONIC National | 0138-0154, 0483, 0653, 1507  |
| PANDA              | 0378, 0890                   |
| PHILCO             | 0210, 0211, 0487, 0488, 1746 |
| PROTON             | 0421-0423, 0933, 1958        |
| RAYBO              | 0362-0367, 1386, 1898        |
| ROWA               | 0369, 0438, 0439, 1393       |
| Sabro              | 0435, 0506-0508, 1018, 1971  |
| SAI JO DENKI       | 0212-0215, 0724, 1750        |

| Brand         | Model Code                   |
|---------------|------------------------------|
| SAMPO         | 0424-0426, 1448, 1961        |
| SAMSUNG       | 0188-0196, 0700, 1726        |
| SANYO         | 0046-0095, 0558, 1582        |
| SASUKI        | 0254, 0470, 0766, 1494       |
| SHANGLING     | 0384-0388, 0444, 0445, 1980  |
| SHARP         | 0096-0106, 0609, 1640        |
| SHINCO        | 0351-0354, 0454-0456, 1887   |
| SHUANGLU      | 0376, 0404-0407, 0480, 1941  |
| SHUAIKANG     | 0288, 0800                   |
| SONGGE        | 0428, 0429, 1453, 1964       |
| SOVA          | 0409, 0410, 0921, 1434       |
| SUMMER        | 0427, 1451                   |
| SUNDURG       | 0257, 0505, 1017, 1793       |
| SWAN          | 0434, 0946                   |
| TADIRAN       | 0246-0251, 0758, 1275        |
| TATUNG        | 0419, 0420, 0932, 1955       |
| TCL           | 0273-0281, 0786, 1305        |
| TECO          | 0256, 0473-0475, 1792        |
| TIANDI        | 0415, 1439                   |
| TOSHIBA       | 0107-0117, 0489, 1001, 1643  |
| TRANE         | 0227-0232, 0739, 1768        |
| UNI-AIR       | 0222-0224, 0450, 0734, 1986  |
| WEILI         | 0393-0396, 0907, 1420, 1929  |
| Whirlpool     | 0164-0170, 0502, 0677, 1706  |
| WINIA         | 0481, 0993                   |
| XILENG        | 0411, 0412, 0924, 1947       |
| XINLE         | 0400, 0401, 0913, 1425, 1936 |
| YANGZI (YAIR) | 0403, 0915                   |
| YINYAN        | 258, 259, 326-331, 0838      |
| YORK          | 0238-0243, 0750, 1266        |
| Zhen bao      | 0129-0136, 1151, 1488, 1664  |

*Uwaga: Klimatyzator musi być wyłączony. Jeśli jest włączony, wyłącz go ręcznie.*

## **KT-SUPER1 to nowy produkt z patentem na ustawienie kodu, wymyślonym przez naszych inżynierów.**

Możesz wprowadzić klawisze numeryczne (0-9) dla wymaganego kodu bezpośrednio, wizualnie, wygodnie, szybko i wydajnie. Ma dokładny zegar, włączanie i wyłączanie timera, wyświetlanie temperatury w pomieszczeniu, konwersje między stopniem Celsjusza a stopniem Fahrenheita. Funkcja uśpienia, pamięć kodów, a także posiada unikalną funkcję „inteligentnego chłodzenia” „inteligentnego ogrzewania”. Więc to jest twój najlepszy kawałek.

Przed użyciem przeczytaj uważnie ten podręcznik, który będzie doskonałą pomocą do korzystania z pilota.

Pilot zdalnego sterowania może być używany po ustawieniu. Pociągnij boczną pokrywę pilota zdalnego sterowania i umieść 2 baterie AAA (UM-4, R03) zgodnie z oznaczeniem biegunowym na obudowie baterii.

### **Utworzenie kodu patentowego**

1. Znajdź kody z tabeli kodów. Dla każdej marki istnieje wiele grup kodów. Wypróbuj pierwszą grupę; jeśli nie obsługuje twojego sprzętu, spróbuj i zrób to tak, aż kody mogą obsługiwać sprzęt. Np. : ALPIN można najpierw wprowadzić 0252; jeśli nie działa, wypróbuj drugi kod 0253 itd.

2. Naciśnij przycisk „SELECT”, kod na wyświetlaczu LCD zacznie migać. Wprowadź kod cyfrowy po kolei. Np. : „0252” naciśnij przycisk „0” „0” przestanie migać, trzy ostatnie cyfry zostaną wygaszone, a ostatnia liczba „2” cały 4-cyfrowy kod „0252” przestanie migać, wpisanie kodu zostało zakończone.

Pilot zdalnego sterowania potwierdza kod automatycznie, a normalnie możesz użyć klawisza numerycznego. Możesz teraz obsługiwać klimatyzator.

3. Włącz klimatyzator i wypróbuj inne klawisze funkcyjne. Jeśli nie działają dobrze, wypróbuj następną grupę kodu, aż wszystkie funkcje będą działać. Pilot zdalnego sterowania ma 2000 kodów w jednym, więc jest nieprawdopodobny, gdy kod jest większy niż 1999.

### **Automatyczne wyszukiwanie kodu ustawienia**

Jeśli nie znasz marki klimatyzatora lub jeśli Twoja marka nie jest wymieniona w tabeli kodów, wykonaj następujące czynności:

1. Umieść cel zdalnego sterowania w klimatyzatorze, naciśnij przycisk „SELECT” przez 5 sekund, a zwolnienie, pilot wejdzie w stan automatycznego wyszukiwania, wysyłaj sygnał w sposób ciągły, kod migocze i rośnie. Gdy klimatyzator odbierze sygnał i wyśle jeden brzęczyk, naciśnij dowolny klawisz, aby potwierdzić.

2. Wypróbuj inne klawisze funkcyjne, jeśli nie działają, powtórz powyższe kroki, aż będzie poprawne.

### **Konfiguracja Clock**

1. Naciśnij przycisk „ZEGAR”, miga sygnał zegara.

2. Naciśnij przycisk „TIME + / TIME-”, aby ustawić czas utwardzania.

3. Naciśnij ponownie przycisk „CLOCK”, a sygnał zegara przestanie migać, ustawienie czasu zakończy się.

(jeśli nie naciśniesz klawisza „zegar”, zakończy się to automatycznie po 15 sekundach)



## Timer włączony

1. Naciśnij przycisk „TIMER ON”, czas na wyświetlaczu LCD miga.
2. Naciśnij przycisk „TIME” +/- ”, wyreguluj yime, aby klimatyzator włączył się automatycznie.
3. Czas na LCD przestanie migać po 15 sekundach. Ustawienie zostało zakończone.

## Timer wyłączony

1. Naciśnij przycisk „TIMER OFF”, czas na LCD miga.
2. Naciśnij przycisk „TIME +/-”, ustaw thime, aby klimatyzator wyłączył się automatycznie.
3. Czas na LCD przestanie migać po 15 sekundach. Settig jest zakończony.

## UWAGA

1. Jeśli dwukrotnie naciśniesz przycisk „TIMER ON” lub „TIMER OFF”, timer zostanie anulowany.
2. Po zakończeniu ustawiania timera, upewnij się, że pilot zdalnego sterowania jest skierowany na odbiornik A / C w prawidłowej odległości i nie ma przeszkód między pilotem a odbiornikiem.

Jeśli nie, nie działa.

3. Jeśli chcesz sprawdzić czas timera, naciśnij przycisk „TIMER włączony lub „TIMER OFF”, wyświetlacz LCD wyświetli czas timera i po 5 sekundach wyświetli aktualny czas.

## Konwersje między stopniem Celsjusza i Fahrenheita

Naciśnij klawisz C / F, aby przekonwertować wyświetlacz między wyświetlaczem Fahrenheita i wyświetlaczem Celsjusza

## Uwaga

1. Jeśli nie jest używany przez dłuższy czas, wyjmij baterię, aby uniknąć wycieku płynu z baterii uszkadzającego urządzenie. Gdy wyświetlacz LCD wygląda na przyciemniony, zmień baterie (nowe i stare baterie nie mogą być używane razem). Po każdej wymianie baterii nie ma potrzeby ponownego ustawiania kodu modelu.
2. Jak zwykle wyświetlacz LCD wyświetla tylko aktualny czas, jeśli chcesz wyświetlić wybrany kod, naciśnij przycisk „ENTER”. Po 5 sekundach ponownie wyświetli aktualny czas.
4. Jeśli włącznik / wyłącznik czasomierza nie działa, sprawdź dokładnie, czy nie ma przeszkód między pilotem a klimatyzatorem. Ponieważ działanie jest skuteczne tylko wtedy, gdy klimatyzator odbierze sygnał włączenia / wyłączenia timera z pilota zdalnego sterowania.
4. Producent zachowuje prawo do zmiany parametru i funkcji produktu.

## Parametry techniczne

Sterowana odległość:> 8 metrów

Napięcie zasilania: DC3 v

Model baterii: Bateria AAA (UM-4, R03) x2

Wymiary: L166mm x W57mm x D19,5mm

Waga: Aprox 110g (bez baterii)

