

Zamiennik Pilota Firmy MEDION 40032820 Opis przycisków

ELMIX-W.LIS

00-138 Warszawa, Pl. Mirowski 1/30

Tel: 602237012, piloty-sklep@wp.pl



Layout Keys	TV
	Brand: MEDION Model: 40032820
	Code Name
POWER	POWER
MUTE	MUTE
PREV/LIST	FAV -
NEXT/USB	FAV +
i+/INFO	INFO
INPUT/AV	INPUT
TIMER/SLEEP	Sleep Timer
SUBT.	SUB-T
EXPAND/PIP	DVD Goto
TEXT/TTX	Text, DVD Angle
EPG	EPG, DVD Title
REVEAL/PLAY	PLAY
TEXT STOP	STOP
INFO/PAUSE	PAUSE
RED	Red, DVD Program
GREEN/REW	Green, DVD Intro
YELLOW	Yellow, DVD Repeat
BLUE/FWD	Blue, DVD A-B
MENU	MENU
UP	UP
EXIT/CANCEL	Exit, DVD Setup
LEFT	LEFT
OK	OK
RIGHT	RIGHT
SOUND/AUDIO	S.MODE
DOWN	DOWN
PICTURE	P.MODE
VOL+	VOL+
BACK	Previous Program
CH+	CH+
VOL-	VOL-
TV/3D/DTV	TV/Radio, DVD Menu
CH-	CH-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
GUIDE/1./1/--	PC Auto, DVD Eject
0	0
FAV/2./P/C	Favourites