

Remote Control -TV Setting Table

ELMIX-W.LIS

00-138 Warszawa Pl. Mirowski 1/30 NIP:5261016149

Contact: piloty-sklep@wp.pl / Tel 602237012

www.piloty-sklep.com.pl



Layout Keys	TV	
	Brand:PHILIPS Model:RCMWT1231T 102921	
POWER		POWER
MUTE		MUTE
PREV/LIST		PR.LIST
NEXT/USB		HDMI
i+/INFO		INFO
INPUT/AV		SOURCE
TIMER/SLEEP		SLEEP
SUBT.		SUBT./NAPISY
EXPAND/PIP		SIZE
TEXT/TTX		TELETEXT
EPG		EPG
REVEAL/PLAY/▶		REVEAL
TEXT STOP/■		HOLD
INFO/PAUSE/		INDEX
RED/●		RED
GREEN/REW/◀		GREEN
YELLOW		YELLOW
BLUE/FWD/▶		BLUE
MENU	MENU	MENU/EXIT
UP	▲	GÓRA
EXIT/CANCEL	EXIT	FORMA
LEFT	◀	LEFT
OK	OK	OK
RIGHT	▶	RIGHT
SOUND/AUDIO		AUDIO ADJ
DOWN	▼	DÓŁ
PICTURE		VIDEO ADJ
VOL+	+V	VOL+
BACK		PRE PR
CH+	+P	CH+
VOL-	-V	VOL-
TV/3D/DTV		ECO
CH-	-P	CH-
1	1./@	1
2	2 abc	2
3	3 def	3
4	4 ghi	4
5	5 jkl	5
6	6 mno	6
7	7 pqrs	7
8	8 tuv	8
9	9 wxyz	9
GUIDE/1./-/-		YPbPr
0	0 _	0
FAV/2./P/C		VIDEO