

Zamiennik pilota model GK23J2 Setting Table

ELMIX. W-LIS

00-138 WARSZAWA PL.MIROWSKI 1/30

tel. 602237012,e-mail:piloty-sklep@wp.pl



Layout Keys	TV
	Brand:CHANGHONG Model:GK23J2
	Code Name
POWER	POWER
MUTE	MUTE
PREV/LIST	PROG
NEXT/USB	HDMI
i+/INFO	Display
INPUT/AV	AV
TIMER/SLEEP	SLEEP
SUBT.	PIP Size
EXPAND/PIP	PIP
TEXT/TTX	text
EPG	PIP Position
REVEAL/PLAY	PIP PROG+
TEXT STOP	PIP PROG-
INFO/PAUSE	Index
RED	RED
GREEN/REW	GREEN
YELLOW	YELLOW
BLUE/FWD	BLUE
MENU	MENU
UP	UP
EXIT/CANCEL	EXIT/CANCEL
LEFT	LEFT
OK	OK
RIGHT	RIGHT
SOUND/AUDIO	S.MODE
DOWN	DOWN
PICTURE	P.MODE
VOL+	VOL+
BACK	Recall
CH+	CH+
VOL-	VOL-
TV/3D/DTV	Scan
CH-	CH-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
GUIDE/1./1/--	CC
0	0
FAV/2./P/C	FAVS