

## PILOT ZAMIENNIK YLP187R Setting Table

ELMIX-W.LIS

00138 WARSZAWA PL. MIROWSKI 1/ 30

TEL. 602237012/piloty-sklep@wp.pl



Layout Keys	TV
	Brand:BEKO Model:YLP187R
	Code Name
POWER	Standby
MUTE	MUTE
PREV/LIST	DVD Backward
NEXT/USB	DVD Forward
i+/INFO	Info, DVD Display
INPUT/AV	AV
TIMER/SLEEP	Zoom
SUBT.	Subtitle
EXPAND/PIP	16:9, DVD Angle
TEXT/TTX	Text/Mix
EPG	EPG, DVD Goto
REVEAL/PLAY	DVD Play
TEXT STOP	DVD Stop
INFO/PAUSE	DVD Pause
RED	Red, DVD Title
GREEN/REW	Green, DVD Root
YELLOW	Yellow, DVD Repeat
BLUE/FWD	Blue, DVD A-B
MENU	MENU
UP	UP
EXIT/CANCEL	Exit, DVD Clear
LEFT	LEFT
OK	OK, Programme List
RIGHT	RIGHT
SOUND/AUDIO	S.MODE
DOWN	DOWN
PICTURE	P.MODE
VOL+	VOL+
BACK	BACK
CH+	CH+
VOL-	VOL-
TV/3D/DTV	PIP, DVD Eject
CH-	CH-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
GUIDE/1./1/--	Swap
0	0
FAV/2./P/C	Favourites, DVD Program