

PILOT ZAMIENNIK RCGU37FHD Setting Table

ELMIX-W.LIS

00138 WARSZAWA PL. MIROWSKI 1/ 30

TEL. 602237012/piloty-sklep@wp.pl



Layout Keys	TV
	Brand:GRUNDIG Model:RCGU37FHD
	Code Name
POWER	POWER
MUTE	MUTE
PREV/LIST	Fast Reverse, FAV -
NEXT/USB	Fast Forward, FAV +
i+/INFO	Display
INPUT/AV	Source
TIMER/SLEEP	TIMER/SLEEP
SUBT.	SUB-T.
EXPAND/PIP	Format, Text Size
TEXT/TTX	Text
EPG	EPG
REVEAL/PLAY	PLAY
TEXT STOP	Stop
INFO/PAUSE	PAUSE
RED	RED
GREEN/REW	GREEN
YELLOW	YELLOW
BLUE/FWD	BLUE
MENU	MENU
UP	UP
EXIT/CANCEL	EXIT
LEFT	LEFT
OK	ENTER
RIGHT	RIGHT
SOUND/AUDIO	S.MODE
DOWN	DOWN
PICTURE	P.MODE
VOL+	VOL+
BACK	Previous Programme
CH+	CH+
VOL-	VOL-
TV/3D/DTV	TV/Radio
CH-	CH-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
GUIDE/1./1/--	Sound I/II, NICAM
0	0
FAV/2./P/C	Favourites