

Remote Control -TV Setting Table

ELMIX-W.LIS

00-138 Warszawa Pl. Mirowski 1/30 NIP:5261016149

Contact: piloty-sklep@wp.pl / Tel 602237012

www.piloty-sklep.com.pl



ELMIX-W.LIS 16-06-2016

Layout Keys	TV	
	Brand: IYYAMA MODEL: 290270006 PART No: 103680	
① POWER		POWER
② MUTE		MUTE
③ PREV/LIST		PIP Swap
④ NEXT/USB		PIP Source
⑤ i+/INFO		Mode Info
⑥ INPUT/AV		AV/SOURCE
⑦ TIMER/SLEEP		TIMER/SLEEP
⑧ SUBT.		S-Video
⑨ EXPAND/PIP		PIP Size
⑩ TEXT/TTX		TEXT
⑪ EPG		PIP Position
⑫ REVEAL/PLAY/▶		Size
⑬ TEXT STOP/■		Scaling, Format
⑭ INFO/PAUSE/		PC Mode
⑮ RED/●		RED
⑯ GREEN/REW/◀		GREEN
⑰ YELLOW		YELLOW
⑱ BLUE/FWD/▶		BLUE
⑲ MENU	MENU	MENU
⑳ UP	▲	Cursor Up
㉑ EXIT/CANCEL		Freeze
㉒ LEFT	◀	Cursor <
㉓ OK		Scart/D4
㉔ RIGHT	▶	Cursor >
㉕ SOUND/AUDIO		CCD, Subtitle (NTSC)
㉖ DOWN	▼	Cursor Down
㉗ PICTURE		Main Mode, System
㉘ VOL+	+V	Volume +
㉙ BACK		R, Return, Previous Programme
㉚ CH+	+P	Programme +
㉛ VOL-	-V	Volume -
㉜ TV/3D/DTV		TV
㉝ CH-	-P	Programme -
㉞ 1	1./@	1
㉟ 2	2 abc	2
㊱ 3	3 def	3
㊲ 4	4 ghi	4
㊳ 5	5 jkl	5
㊴ 6	6 mno	6
㊵ 7	7 pqrs	7
㊶ 8	8 tuv	8
㊷ 9	9 wxyz	9
㊸ GUIDE/1./!/-		YPbPr1
㊹ 0	0_	0
㊺ FAV/2./P/C		YPbPr2