

## Remote Control -TV Setting Table

ELMIX-W.LIS

00-138 Warszawa Pl. Mirowski 1/30 NIP:5261016149

Contact: piloty-sklep@wp.pl / Tel 602237012

www.piloty-sklep.com.pl



Layout Keys	TV	
	Brand:LG Model:MKJ42519618, AKB69680403	
	104082,104083	
POWER		POWER
MUTE		MUTE
PREV/LIST		LIST
NEXT/USB		AV MODE
i+/INFO		INFO
INPUT/AV		INPUT
TIMER/SLEEP		T.OPT
SUBT.		SUBT./NAPISY
EXPAND/PIP		FREEZE
TEXT/TTX		TEXT
EPG		SIMPLINK
REVEAL/PLAY/▶		PLAY
TEXT STOP/■		STOP
INFO/PAUSE/		PAUSE
RED/●		RED
GREEN/REW/◀		GREEN
YELLOW		YELLOW
BLUE/FWD/▶		BLUE
MENU		MENU
UP		UP
EXIT/CANCEL		RETURN/EXIT
LEFT		LEFT
OK		OK
RIGHT		RIGHT
SOUND/AUDIO		TV/RADIO
DOWN		DOWN
PICTURE		Q.MENU
VOL+		VOL+
BACK		Q.VIEW
CH+		CH+
VOL-		VOL-
TV/3D/DTV		ENERGY SAVING
CH-		CH-
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
GUIDE/1./1/--		GUIDE
0		0
FAV/2./P/C		FAV/MARK