

## PILOT ZAMIENNIK 2T3601 Setting Table

ELMIX-W.LIS

00138 WARSZAWA PL. MIROWSKI 1/ 30

TEL. 602237012/piloty-sklep@wp.pl



| Layout Keys   | TV                        |
|---------------|---------------------------|
|               | Brand:ECG<br>Model:2T3601 |
|               | Code Name                 |
| POWER         | POWER                     |
| MUTE          | MUTE                      |
| PREV/LIST     | Favourite -               |
| NEXT/USB      | Favourite +               |
| i+/INFO       | DISPLAY                   |
| INPUT/AV      | INPUT                     |
| TIMER/SLEEP   | SLEEP                     |
| SUBT.         | SUBT                      |
| EXPAND/PIP    | Aspect                    |
| TEXT/TTX      | TEXT                      |
| EPG           | EPG                       |
| REVEAL/PLAY   | NICAM                     |
| TEXT STOP     | Index                     |
| INFO/PAUSE    | AUTO                      |
| RED           | RED                       |
| GREEN/REW     | GREEN                     |
| YELLOW        | YELLOW                    |
| BLUE/FWD      | BLUE                      |
| MENU          | LCD MENU                  |
| UP            | UP                        |
| EXIT/CANCEL   | EXIT                      |
| LEFT          | LEFT                      |
| OK            | OK                        |
| RIGHT         | RIGHT                     |
| SOUND/AUDIO   | S.MODE                    |
| DOWN          | DOWN                      |
| PICTURE       | P.MODE                    |
| VOL+          | VOL+                      |
| BACK          | Previous Programme        |
| CH+           | CH+                       |
| VOL-          | VOL-                      |
| TV/3D/DTV     | Audio Lang.TV/RADIO       |
| CH-           | CH-                       |
| 1             | 1                         |
| 2             | 2                         |
| 3             | 3                         |
| 4             | 4                         |
| 5             | 5                         |
| 6             | 6                         |
| 7             | 7                         |
| 8             | 8                         |
| 9             | 9                         |
| GUIDE/1./1/-- | -/--                      |
| 0             | 0                         |
| FAV/2./P/C    | FAV                       |